Philips
Cleaning tool

CRP769

To clean the rollerbrush and dustcontainer.

Find matching products on the specifications tab

The cleaning tool helps to clean the HomeRun. The brush side can be used to remove fluff and dirt from the internals of the appliance, the teethed part can be used to remove entangled hairs from the rollerbrush.

PHILIPS
sense and simplicity

Specifications

Replaceable part
- Fits product type :: FC9910/01/A, FC9910/01/B

Suitable for
- HomeRun: FC9910/01/A, FC9910/01/B

Issue date 2012-11-27

Version: 1.0.1

© 2012 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com